

EHS

**IMPORTANT INFORMATION
READ BEFORE OPERATING**

**Burnout Instructions
&
Adding and Removing Channels
For the Chino AL/AH3000 Recorders**

**ELECTRIC HEATING SYSTEMS, INC.
109 NORTH GOLD DRIVE
ROBBINSVILLE, NJ 08691
PHONE # (609) 259-4116
FAX # (609) 259-4119
WEB SITE www.EHSUSA.com
E-MAIL: ElecHtgSys@aol.com**

Electric Heating Systems Inc.
109 North Gold Drive Robbinsville, NJ 08691
(609) 259-4116 (24/7) Fax (609) 259-4119

ADDING and DELETING CHANNELS on the CHINO AH-3000 RECORDERS

To delete channels (skip) on the Chino AH-3000 digital recorders a simple procedure must be followed.

1. Hold the **SHIFT** + **7** Keys together to get to the Range parameter.
2. Press the **SET** Key to enable value changes to be entered. An underline (cursor) will be seen under the first two numbers. This is the channel number to be configured.
3. Select the channel to be deleted by pressing the UP or DOWN Arrow keys.
4. Press the **SHIFT** + **CLEAR** keys together. The channel will now be empty (cleared).
5. Press the **ENTRY** key to temporarily store this value into memory.
6. Press the **SHIFT** + **SET** keys together to store these settings and to return to the home screen.

To restore deleted channels on the Chino AH-3000 digital recorders a simple procedure must be followed.

7. Hold the **SHIFT** + **7** Keys together to get to the Range parameter.
8. Press the **SET** Key to enable value changes to be entered. An underline (cursor) will be seen under the first two numbers. This is the channel number to be configured.
9. Select the channel to be restored by pressing the UP or DOWN Arrow keys.
10. The following values are the generally used values for heat treating purposes.

01:2310 $\overline{}$ 2000

This represents channel 1 (01), (23)Type K thermocouples, (1)an internal cold junction value, (0 to 2000) 0 degrees F. to 2000 degrees F. range. Press the **ENTRY** key to temporarily store this value into memory.

When these values are entered for each of the channels to be restored, Press the **SHIFT** + **SET** keys together to store these settings and to return to the home screen.

Electric Heating Systems Inc.
109 North Gold Drive Robbinsville, NJ 08691
(609) 259-4116 (24/7) Fax (609) 259-4119

Burnout Settings for the Chino AH-3000 Recorders

To avoid a potential electronic backfeed from the Chino AL/AH-3000 recorders to the Controllers or a Programmer, it is recommended to use the following procedure.

1. **Up scale burn-out** any thermocouple input to the recorder that is open (not being used) should be programmed with **up-scale** burnouts. For example, if channels 1 through 7 were being used, then channels 8 through 12 (on a 12-point recorder) would be set with up-scale burnout.
2. **Down scale burn-out** Not generally used in heat-treating
3. **Non burn-out** any thermocouple input to the recorder that is being used (active/reading a T.C.) should be programmed with **Non-burnout**.

Procedure for entering burn-outs:

1. Press **both** the **SHIFT** button and the **DOWN ARROW** button together and **hold** them both for five (5) seconds. Display will show...01 = *Up bUrn*
2. Press the **SET** button to enable changes to be made. A cursor (underline) will appear under the first two numbers. These numbers indicate the channel to be programmed.
3. Scroll to the channel to be set by using either the **ENTER** key or the **UP** or **DOWN ARROW** keys. In our example we will scroll to channel 8.
4. Move the cursor under the type of burnout desired by using the **RIGHT ARROW** key. There are three possible settings. **UP DOWN** or **NON**. UP is for up-scale burnouts, DOWN is for down-scale burnouts and NON is for no burnouts.
5. Scroll through the three burnout options by using the **UP** or **DOWN ARROW** keys. For our example we will set channel 8 with an **UP-SCALE** burnout. Push the **ENTER** key to enter the setting for channel 8.
6. Repeat this procedure for channels 9 through 12.
7. After all the channels have been programmed as desired it is necessary to store the settings into memory. To do this, press the **SHIFT** button and the **SET** button **together**. The recorder will store the settings into memory and return to the original display screen.